How to debug a program at the machine instruction level

version	1.1.1
scope	Example. This code is provided as example code for a user to base their code on.
description	How to debug a program at the machine instruction level
boards	Unless otherwise specified, this example runs on the SliceKIT Core Board, but can easily be run on any XMOS device by using a different XN file.

As well as working at the source level, XGDB can be used to debug programs at the level of the machine instructions. As an example, consider the following program:

```
int main() {
  int i, j = 0;
  for (i = 0; i < 5; ++i) {
    j += i;
  }
  return 0;
}
```

Compile the above program ensuring that debug is enabled (-g):

1 From xTIMEcomposer Studio

Create a new debug configuration via *Run->Debug Configurations->xCORE Applications*. Set a breakpoint on *main* and start debugging. Execution will now break when *main* is reached. Open both the *Disassembly* and the *Debug* views. In the *Debug* view toolbar, click on the *Instruction Stepping Mode* button. When in this mode, a single step will now correspond to a single machine instruction and not a source line. This can be seen by stepping a few times and watching the progress in the *Disassembly* view.

2 From the command line

Start XGDB, connect to the simulator and set a breakpoint on *main*. Execution will therefore suspend when the *main* is reached. The *stepi* command can be used to

XMOS®

step a single machine instruction, and the *disassemble* command can be used to see the disassembly of the code close to the current PC location:

```
> xgdb a.xe
..etc..
(gdb) connect -s
0xffffc070 in ?? ()
(gdb) b main
Breakpoint 1 at 0x100b0: file debugging_at_the_instruction_level.xc, line
    ↪ 9.
(gdb) r
...etc...
Breakpoint 1, main () at debugging_at_the_instruction_level.xc:9
9       int i, j = 0;
(gdb) disassemble
Dump of assembler code for function main:
0x000100ac <main+0>:        entsp (u6)      0x4
0x000100ae <main+2>:        ldc (ru6)       r0, 0x0
0x000100b0 <main+4>:        stw (ru6)       r0, sp[0x0]
0x000100b2 <main+6>:        stw (ru6)       r0, sp[0x1]
0x000100b4 <main+8>:        bu (u6)         0x7
0x000100b6 <main+10>:       ldw (ru6)       r0, sp[0x1]
0x000100b8 <main+12>:       ldw (ru6)       r1, sp[0x0]
0x000100ba <main+14>:       add (3r)        r0, r1, r0
0x000100bc <main+16>:       stw (ru6)       r0, sp[0x0]
0x000100be <main+18>:       ldw (ru6)       r0, sp[0x1]
0x000100c0 <main+20>:       add (2rus)      r0, r0, 0x1
0x000100c2 <main+22>:       stw (ru6)       r0, sp[0x1]
0x000100c4 <main+24>:       ldw (ru6)       r0, sp[0x1]
0x000100c6 <main+26>:       ldc (ru6)       r1, 0x5
0x000100c8 <main+28>:       lss (3r)        r0, r0, r1
0x000100ca <main+30>:       bt (ru6)        r0, -0xb
0x000100cc <main+32>:       bu (u6)         0x0
0x000100ce <main+34>:       ldc (ru6)       r0, 0x0
0x000100d0 <main+36>:       stw (ru6)       r0, sp[0x2]
0x000100d2 <main+38>:       ldw (ru6)       r0, sp[0x2]
0x000100d4 <main+40>:       retsp (u6)      0x4
End of assembler dump.
(gdb) stepi
10      for (i = 0; i < 5; ++i) {
(gdb) stepi
0x000100b4  10          for (i = 0; i < 5; ++i) {
(gdb) stepi
0x000100c4  10          for (i = 0; i < 5; ++i) {
(gdb) stepi
0x000100c6  10          for (i = 0; i < 5; ++i) {
(gdb) stepi
0x000100c8  10          for (i = 0; i < 5; ++i) {
...etc...
```