

Application Note: AN10060

How to dynamically change the type of a port

This application note is a short how-to on programming/using the xTIMEcomposer tools. It shows how to dynamically change the type of a port.

Required tools and libraries

This application note is based on the following components:

- xTIMEcomposer Tools - Version 14.0.0

Required hardware

Programming how-tos are generally not specific to any particular hardware and can usually run on all XMOS devices. See the contents of the note for full details.

1 How to dynamically change the type of a port

When you declare a port, you declare it as an in or out port or possibly as buffered.

```
out port p = XS1_PORT_1A;
```

Sometimes you need to change the port type dynamically during the execution of a program. This can be done with the `reconfigure_port` function.

```
int main() {
```

To reconfigure a port you need to create movable pointers for the port you want to reconfigure and the reconfigured port.

```
out port * movable pp = &p;  
buffered out port:32 * movable buffered_p;
```

The `reconfigure_port` function works by transferring the ownership of the port from one movable pointer to another. This means that after this function is called you cannot use the original port configuration.

```
buffered_p = reconfigure_port(move(pp), buffered out port:32);
```

After reconfiguring the port, the port can be accessed via the pointer.

```
*buffered_p <: 0xa0a0a0a0;
```

After the program has finished using the reconfigured port it needs to pass ownership back to the original port pointer (by reconfiguring it back to the original type).

```
pp = reconfigure_port(move(buffered_p), out port);
```