

Application Note: AN10025

How to pass pointers over interface calls

This application note is a short how-to on programming/using the xTIMEcomposer tools. It shows how to pass pointers over interface calls.

Required tools and libraries

This application note is based on the following components:

- xTIMEcomposer Tools - Version 14.0.0

Required hardware

Programming how-tos are generally not specific to any particular hardware and can usually run on all XMOS devices. See the contents of the note for full details.

1 How to pass pointers over interface calls

Interface functions can take pointer arguments:

```
interface my_interface {  
    void msg(int *p);  
};
```

The client end can then pass a pointer into the function:

```
void task1(client interface my_interface c)  
{  
    int a[5] = {0,1,2,3,4};  
    int *p = &a[0];  
    c.msg(p);  
}
```

On the server end the select case can access memory via the pointer.

```
void task2(server interface my_interface c)  
{  
    select {  
    case c.msg(int *p):  
        printintln(*p);  
        printintln(*(p+2));  
        break;  
    }  
}
```

Since passing the pointer implies that both tasks need access to the same memory space, if an interface includes a function that passes pointers, you cannot use it between tasks on different tiles.